



INTEGRATION GUIDE

How to Configure Mist to Secure your Wireless Network with Portnox CLEAR Portnox Integration Guide

Introduction

This document guides you step by step how to configure your Mist wireless environment using Portnox CLEAR to ensure secure and trusted user access.

Enabling CLEAR RADIUS Service

The first step is to enable the CLEAR RADIUS service:

- 1) Verify your organization is registered on Portnox CLEAR Cloud Services: https://clear.portnox.com/.
- 2) In the CLEAR portal, go to **Settings** > **Services** and expand **CLEAR RADIUS Service**. Then:
 - a. If the **Enable Cloud RADIUS** checkbox is not checked, click **Edit** and check the **Enable Cloud RADIUS** checkbox.
 - b. Note the RADIUS server details which you will need when configuring the Mist SSID:
 - Cloud RADIUS IP this is the IP address of the CLEAR RADIUS server
 - Authentication port
 - Accounting port needed for the RADIUS accounting server
 - Shared Secret this is the RADIUS client shared secret

Registering the SSID in CLEAR


The second step is to register, in the CLEAR portal, the SSID of the wireless network you will be securing.

- 1) Navigate in the portal to **Groups**.
- 2) Edit the default "Unassigned" group or create a new security group.
- 3) Whether you are creating or editing a group, in **Group Settings** click **Add Wi-Fi network** and specify the **SSID** of the network you will be securing.

Configuring the Mist Wireless SSID

In the final step, we configure the Mist wireless SSID to be secured and protected based on CLEAR RADIUS authentication.

- 1) In the Mist portal, navigate to **Network > WLANs**, and add a new WLAN or edit an existing one.
- 2) In the SSID's Security section, Select WPA-2/EAP (802.1X).
- 3) In the Radius section, do the following:
 - a. Add Radius authentication server. Enter the following CLEAR RADIUS server details, which you noted in Enter the following CLEAR RADIUS server details, which you noted in Enter the following CLEAR RADIUS server details, which you
 - In RADIUS Server, enter the Cloud RADIUS IP.
 - In **RADIUS Port**, enter the Authentication port number.
 - In RADIUS Secret, enter the Shared Secret.



- b. Add radius accounting server. Enter the following CLEAR RADIUS Accounting server details, which you noted in Enabling CLEAR RADIUS Service, step (2)b:
 - In RADIUS Accounting Server, enter the Cloud RADIUS IP.
 - In RADIUS Accounting Port, enter the Accounting port number.
 - In RADIUS Accounting Secret, enter the Shared Secret.

