





INTEGRATION GUIDE

How to Configure WatchGuard Firebox Wireless Controller to Secure your Wireless Network with Portnox CLEAR

Introduction

This document guides you step by step how to configure your WatchGuard wireless environment using Portnox CLEAR to ensure secure and trusted user access.

Enabling CLEAR RADIUS Service

The first step is to enable the CLEAR RADIUS service:

- 1) Verify your organization is registered on Portnox CLEAR Cloud Services: https://clear.portnox.com/.
- 2) In the CLEAR portal, go to Settings > Services and expand CLEAR RADIUS Service. Then:
 - a. If the **Enable Cloud RADIUS** checkbox is not checked, click **Edit** and check the **Enable Cloud RADIUS** checkbox.
 - b. Note the RADIUS server details which you will need when configuring the WatchGuard switch:
 - Cloud RADIUS IP this is the IP address of the CLEAR RADIUS server
 - Authentication port
 - Accounting port needed for the RADIUS accounting server
 - Shared Secret this is the RADIUS client shared secret

Registering the SSID in CLEAR

The second step is to register, in the CLEAR portal, the SSID of the wireless network you will be securing.

- 1) Navigate in the portal to **Settings** > **Groups**.
- 2) Edit the default "Unassigned" group or create a new security group.
- 3) Whether you are creating or editing a group, in **Group Settings** click **Add Wi-Fi network** and specify the **SSID** of the network you will be securing.

Configuring the WatchGuard Wireless SSID

In the final step, we configure the WatchGuard wireless SSID to be secured and protected based on CLEAR RADIUS authentication.

- 1) In the WatchGuard web interface, navigate to **Network** > **Gateway Wireless Controller** > **SSIDs**, and add a new SSID or edit an existing one.
- 2) In the SSID's **Security** tab, do the following:
 - a. Select WPA/WPA2 Enterprise as the Security Mode.
 - b. Select an Encryption type: AES / TKIP or AES.
 - c. Enter the following CLEAR RADIUS server details, which you noted in <u>Enabling CLEAR RADIUS</u> <u>Service</u>, step (2)b:
 - In RADIUS Server, enter the Cloud RADIUS IP.
 - In RADIUS Port, enter the Authentication port number.
 - In **RADIUS Secret**, enter the Shared Secret.
 - d. Check the Enable RADIUS Accounting check box.
 - e. Enter the following CLEAR RADIUS Accounting server details, which you noted in Enabling CLEAR RADIUS Service, step (2)b:
 - In RADIUS Accounting Server, enter the Cloud RADIUS IP.
 - In RADIUS Accounting Port, enter the Accounting port number.
 - In RADIUS Accounting Secret, enter the Shared Secret.
 - f. Click save.

WatchGuard	Fireware Web UI	
DASHBOARD SYSTEM STATUS NETWORK	Gateway Wireless Controller / S	SSID WG-CLEAR
Interfaces ARP Entries	Settings Security	Access Points
Link Aggregation VLAN	Security Mode	WPA/WPA2 Enterprise
Bridge Loopback	Encryption	AES
Multi-WAN Dynamic DNS	Group Key Update Interval	3600
NAT Routes	RADIUS Server	
Dynamic Routing Gateway Wireless Controller	RADIUS Port	
Modem FIREWALL	RADIUS Secret	
SUBSCRIPTION SERVICES AUTHENTICATION VPN	Enable RADIUS Accounting RADIUS Accounting Server	
SYSTEM	RADIUS Accounting Port	
	RADIUS Accounting Secret	
	Interim Accounting Interval	600
	 Enable Fast Roaming (802.1 Fast Roaming requires WPA2 SAVE CANCEL 	1k, 802.11r) 2 authentication and only applies to supported devices.